


MG/300RG MG/300LG




Technical manual





Nr.	spare part	Code nr.
1	Shelf	004010368
2	Shelf support clip	013010001
3	Shelf climbing strip	251125BE
4	Fan motor grid	007030107
5	Starter	008090323
6	Switch ON / OFF	008040101







Nr.	spare part	Code nr.
7	Tube connections	008090337
8	Tube cover	253983A
9	Fluorescent tube	008090212
10	Door gasket	006110488



Nr.	spare part	Code nr.
11	Condenser	002010104
12	Lower door hinge	013040040
	Upper door hinge	013040034
13	Door (complete)	MAXI-FR300LG
		MAXI-FR300RG
14	Lock	013050257 + 013050264
15	Light switch	008040127
16	Thermostat	005050168
	Thermostat cover	005050319
	Sensor thermostat	005050332



Nr.	spare part	Code nr.
17	Block switch	008090333
18	Drain pan	006010107
19	Fan wing	007030302
20	Fan motor	007030243
21	Compressor	001020157
22	Start relais	001050148
22	Clixon	001010121
	Unit	214382D



Nr.	spare part	Code nr.
23	Fan motor (interior)	007030229
24	Junction box	008010418
25	Evaporator	002030181

1	Deur links Antraciet Door left Anthracite Porte gauche anthracite Tür links Antrazite	Maxi-FR300LG
2	Deur rechts Antraciet Door right Anthracite Porte droite anthracite Tür rechts Antrazite	Maxi-FR300RG
3	Deur links Aisi 430 Door left Aisi 430 Porte gauche Aisi 430 Tür links Aisi 430	Maxi-FR300LGCS
4	Deur rechts Aisi 430 Door right Aisi 430 Porte droite Aisi 430 Tür rechts Aisi 430	Maxi-FR300RGCS
	Unit	214382D
5	Handgreep antraciet handle Anthracite Poignée Anthracite Handgriff Antrazite	218580BE+006050132+012080111(2x)
6	Handgreep Aisi 430 handle Aisi 430 Poignée Aisi 430 Handgriff Aisi 430	013020114 +012080113(2x)