



MG/250G







Nr.	spare part	Code nr.
1	Condenser	002010193
2	Ballast (18W)	008090336
3	Compressor	001020238
4	starter kit	001010164
5	Fan motor	007030229
6	Drip tray	006010116



Nr.	spare part	Code nr.
7	Mini fan	007030229
8	Probe thermostat	005050333
9	Evaporator	002030181



Nr.	spare part	Code nr.
10	Shelf	004010386
11	Shelf climbing strip	013070031
12	Shelf support clip	013010001
13	Switch ON / OFF	008040101
14	Fan motor grid	007030107



Nr.	spare part	Code nr.
15	Light starter	008090323
16	Tube/starter connector	008090345
	Tube connector	008090344
17	Tube cover	255556A
18	Fluorescent tube	008090205
19	Adjustable leg	013060056





20

21

22


Nr.	spare part	Code nr.
20	Thermostat	005050168
21	Light switch	008040127
22	Lock (2x)	013050257 + 013050264
23	handle (anthracite)	006050146
	handle (stainless steel)	013020114
24	Door Left anthracite (complete)	MX-BFR250GGL07
	Door Left st. steel (complete)	MX-BFR250GGL31
25	Door Right anthracite (complete)	MX-BFR250GGR07
	Door Right st. steel (complete)	MX-BFR250GGR31




23

24

25





Nr.	spare part	Code nr.
26	Upper door hinge	013040040
27	Door gasket	006110510
28	Lower door hinge	013040040 + 012090702

