



MG/250SD

# MG/250SD







Nr.	spare part	Code nr.
1	Condenser	002010175
2	Ballast (18W)	008090336
3	Compressor	001020190
4	clixon Start Relay	001010155 001050204
5	Fan motor	007030243
6	Fan wing	007030326




<b>Nr.</b>	<b>spare part</b>	<b>Code nr.</b>
7	Mini fan	007030229
8	Probe thermostat	005050333
9	Evaporator	002030181



Nr.	spare part	Code nr.
10	Shelf	004010386
11	Shelf climbing strip	013070031
12	Shelf support clip	013010001
13	Switch ON / OFF	008040101
14	Fan motor grid	007030107



Nr.	spare part	Code nr.
15	Light starter	008090323
16	Tube/starter connector	008090345
	Tube connector	008090344
17	Tube cover	255556A
18	Fluorescent tube	008090205
19	Adjustable leg	013060056



20



Nr.	spare part	Code nr.
20	Lock	013050241
21	Thermostat	005050168
22	Light switch	008040127



21

22

23



24

<b>Nr.</b>	<b>spare part</b>	<b>Code nr.</b>
23	Wiper strip	013080016
24	Wheel	019000038



**Nr. spare part**

**Code nr.**

- 25 handle
- 26 Door back (complete)
- 27 Door front (complete)

- 006050146
- MX-BFR250SGB07
- MX-BFR250SGF07